



# Changing Battery Guide for Roomba 500/600/700 Series

①




Use a Phillips head (+) screwdriver to loosen the screw that hold the side brush which is located at the top left-hand corner of the bottom casing.

②



Remove the side brush.

③




Loosen the four screws as shown in above diagram by using a Phillips head (+) screwdriver.

④




Remove the bottom casing.

⑤



Take out the battery pack from the battery compartment and replace it with the new battery pack.

⑥



Reinstall the bottom casing and the side brush using the original screws. The device is now ready for use.